



NC C NO NC C NO V- V+
RELAY 4 RELAY 3 12VDC OUT

NC C NO NC C NO V- V+
RELAY 2 RELAY 1 12VDC OUT

PRT-IO84-DIN

POWER

STATUS

FAULT

1 2

OUTPUT

3 4

1 2 3 4

INPUT

5 6 7 8

N+ N- NA NB
12VDC IN RS485 NETWORK

V+ V- Z1 C Z2 Z3 C Z4
12VDC OUT ZONE INPUT 1-4

V+ V- Z5 C Z6 Z7 C Z8
12VDC OUT ZONE INPUT 5-8

